

# Using the Zünd

## Machine Startup:

- When the machine starts up for the first time it is **extremely important** that we check that the tool selected for each module is correct and the tools are initialized.
  - If you do not know how to do this please make sure a monitor or technician is present

## Loading Your File:

- Drop your file into the hot folder on the desktop
- Open the Cut Queue and double click on your file. This will open the Cut Center

## Choose your Material:

- Choose your material from the list and input the materials thickness
  - We've placed all standard materials used under SoA Materials
  - Measure your material thickness with a caliper
  - You do not need to put in a length or width.
  - Click OK

## Choose Machining Steps:

- Double click on one of your layers. This will pop up Method Attributes
- Set your method to the operation you want. The most common you will use:
  - **Register**- This is used to register your material boundaries
  - **Draw**- You need the UDT installed, but this is for drawing on your material
  - **Score**- Scores on top of your material
  - **Thru Cut**- Cuts through your material
- Choose Thru Cut or Score for your material. Make sure that the module and tool/blade are correct in the display to what is on the machine.
  - If the wrong tool/blade is shown in the display click on the arrow next to the tool in this dialog box and change it to the tool that is in the cutter.

## Setup your Registration Layer:

- Click on Add a New Machining Step
  - This is the icon that looks like a green plus sign with a tool to the left of it and is above your layers. Hover over the icons if you're unsure
  - Under Method choose Register
  - Change the registration type to **Border: Front, Right**
- Use the blue arrow icons to move the Registration layer to the top of the list

## Double Check Your File:

- Make sure that the tool listed on all your layer is correct and that it matches the tool in the bottom right.
- Make sure that job processing says **Manual Feed**.
- If everything looks correct and nothing in the bottom right is red you may start the job

**Do not change the blade/module by yourself  
Please have a monitor or technician present**

**Ask a monitor or technician to help troubleshoot any problems**

We've had connectivity issues and we need to make sure this is all done properly